

# Number Plate Fitting Guide

[www.englishnumberplates.com](http://www.englishnumberplates.com)

In order to get the very best fitment and finish on your brand new plates supplied by us, simply follow our drilling and fitment guide below.

1. Leave the protective cover on the Perspex number plate until the drilling is complete.
2. Mark drilling holes onto the back of the plate with a soft pencil or felt tip.
3. Place plate face down on a smooth piece of wood.
4. Drill through the marking holes with a 6mm high-speed drill bit, applying high pressure.
5. Do not drill a pilot hole as this may cause cracking.
6. Install plate onto vehicle.

Should you require assistance please contact us using the details on our website.